



Exploded Diagram

Model and code:(PASRW070S-P-BP6III-X 100000001310)

1 Complete machine structure explosion diagram



2 Electrical control structure explosion diagram



No.	Code	Name	Qty
1	807000010504	Chassis Assembly	1
2	80901004	Waterproof cover	1
3	807000010437	Air deflector	1
4	807000010436	Front Panel	1
5	301030-00000003	Axial Flow Fan Blade	1
6	20000-330309	Dc Fan Motor	1
7	807000010425	Left Side Panel	1
8	80715766	Connect Plate	1
9	80715765	Air Ducting	1
10	80715770	Motor Bracket Assembly	1
11	80710049	Top Frame Assembly	1
12	80601520	Fin Heat Exchanger	1
13	807000010421	Top Cover	1
14	807000010424	Back Guard Assembly	1
15	80718969	Electrical Box Cover	1
16	2004-1437	4-Way Valve Assembly	1
17	81000084	Electronic Expansion Valve	1
18	2004-1444	Filter	2
19	20000-140150	Needle Valve	2
20	2000-1460	T-joint	2
21	2001-3605	Pressure Switch	1
22	20000-360157	Pressure Switch	1
23	304030-00000002	T-joint	1
24	20000-370030	Reactor	1
25	807000010423	Right Side Panel Assembly	1
26	83000069	Water Flow Switch	1
27	72300249	Titanium Heat Exchanger	1
28	80715654	Bracket	1
29	80100133	Rotary Compressor	1
30	80718966	Median Septum Assembly	1
31	80718970	Connect Plate	1
32	80718967	Liner Plate	1
33	72200741	Controller Circuit Board Assembly	1
34	/	Terminal Block	1
35	/	Terminal Block	1
36	20000-360297	Electromagnetic Relay	1
37	82300329	Inverter Driver Module	1
38	2000-3909	Wiring Terminal Block	2
39	80718968	Liner Plate	1
40	/	Terminal Block	1
41	/	Terminal Block	1
42	82300074	Power Supply Filter	1
43	20000-390047	Terminal Block	3
44	72200684	Control Assembly	1
45	302010-00000014	Inverter Capacitor Board	1
46	80718965	Electrical Box Assembly	1